

INSTALLATION MANUAL

2,000 and 2,000+ Hanger Model 2,000 and 2,000+ Barb x Barb Model







42371 Avenida Alvarado, Temecula, CA 92590 TOLL FREE: (800) 454-2725 TEL: (951) 296-3480 FAX: (951) 296-3490 www.aquauv.com







TABLE OF CONTENTS

1
2 Warranty
Introduction
4 How Ultraviolet Works
4 Sizing Chart
5 Frequently Asked Questions
6 Pond/Aquarium Layouts
7 Hanger Installation Instructions
8 Barb X Barb Installation Instructions
9Trouble Shooting Leaks
10Installing The Lamp
11
12
14
15 Replacement Parts
To the state of th

THANK YOU FOR PURCHASING THE BEST ULTRAVIOLET SYSTEM

IMPORTANT INFORMATION



WE CAN HELP YOU

Returning this product is expensive and time consuming for you, your retailer and for us, the manufacturer. Should you encounter any problems with your product, please call our toll free "HELP" line for assistance 1-800-454-2725.

PLEASE DO NOT return your product to the store! Your dealer or distributor cannot offer any warranty work or exchanges on your product.



In the US please call
TOLL FREE 1-800-454-2725
(951) 296-3480 Outside the U.S.
THANK YOU!

WARRANTY INFORMATION

Aqua Ultraviolet systems are warranted against failure due to defects in materials and/or workmanship during the warranty period. This warranty covers defects occurring under normal use and applies to the original retail purchaser and may not be transferred. The warranty and remedies set forth herein are conditional upon proper storage, installation, use, maintenance and conformance with the applicable use. It will be based upon Aqua Ultraviolet's discretion as to whether the defects are of manufacturing origin. Any damages due to shipping and handling, packing, or installation are not covered by this warranty.

This warranty does not apply to appearance or accessory items. This warranty does not include damage due to handling, transportation, unpacking, set up, installation, repair or replacement of parts supplied by any other than Aqua Ultraviolet, improper maintenance, incorrect line voltage, modification, or repairs by the purchaser, abuse, misuse, neglect, accident, fire, flood, or other acts of God.

Any oral statements about the product made by the seller, the manufacturer, their representatives or any other parties do not constitute warranties and shall not be relied upon by the user and are not part of this contract.

Neither the seller nor the manufacturer shall be liable for any injury, loss or damages, whether direct, incidental or consequential including but not limited to lost profits, lost sales, injury, inability to use the product and the user agrees that no other remedy is available.

Before installing, the user shall determine the suitability of the product for their intended use and the user shall assume all risk liability whatsoever in connection therewith.

To validate this warranty, mail the enclosed warranty card within 10 days of purchase along with proof of purchase (copy of sales receipt).

Warranty Period:

Housing: Limited lifetime warranty on housing against Ultraviolet degradation.

Complete Unit: One year from the date of purchase or 18 months from manufacturing date.

Limitations:

Warranty does not cover any malfunction from improper installation.

Warranty only applies to the original end user and is not transferable.

Warranty does not cover repairs done by anyone other than Aqua Ultraviolet.

Warranty is void if system is not plugged into a G.F.C.I. (Ground Fault Current Interrupter).

Warranty may not be modified by verbal statements by Aqua Ultraviolet, distributors, retailers, their agents or any other party.

Warranty covers the repair or prorated replacement of the Aqua Ultraviolet products. Aqua Ultraviolet denies all liability for any other loss including but not limited to loss of equipment, income, livestock or personal injury.

There is no warranty on the Quartz Sleeve.

There is no warranty on broken lamps. Lamps are prorated by usage.

Warranty is voided by the following:

Product labels defaced or removed.

Housing has been painted.

Product is improperly installed or maintained by user or agent.

Product is abused, misused or damaged by user or their agent.

Product damage is caused by electrical surges, electrical spikes, electrical brown outs or improper voltage.

Electrical cord has been cut.

Unit was run without water.

Use of other than Genuine Aqua Ultraviolet Parts.

WARRANTY RETURN AND REPAIR

Any implied warranty granted under state law including warranties of merchantability or fitness for a particular purpose are limited to one year from the date of purchase or 18 months from the date of manufacture or as otherwise stated in the above warranty. Aqua Ultraviolet is not responsible for direct, indirect, incidental or consequential damages. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusions or limitations of incidental damages so the above limitation and exclusion may not apply to you. This warranty gives you special legal rights and you may also have other rights that vary from state to state.

Warranty Returns or Repair Returns:

Please call Aqua Ultraviolet at (800) 454-2725 for a "Return Merchandise Authorization" (RMA) number. You must have a valid RMA from an Aqua Ultraviolet customer service representative before sending any product in for warranty or repair. Please have your serial number, date of purchase and product type available when calling for an RMA number.

All warranty returns or repair returns must come freight prepaid with an RMA number clearly marked on the outside of the box. All other returns will be refused. Aqua Ultraviolet will not be liable for any shipping cost to return warranty or repair items. Include a note in the box with your RMA number, name, address, daytime phone number and brief description of the reason for return or repair.

Be sure to return product in the same packing or similar packing and insure the package (we recommend sending it UPS). If you do not have or can't locate proper packaging, please call our customer service department and we will send you packaging for a minimal charge.

Aqua Ultraviolet shall not be responsible for damage or loss done by the shipper. Nor shall Aqua Ultraviolet be responsible for merchandise that arrives damaged due to improper packaging. All claims for loss and damage must be filed by the customer with the shipper.

If the unit is found to be out of warranty we will contact you with the cost of repair. Your authorization is required prior to making any repairs.

We at Aqua Ultraviolet would like to take the time to thank you for purchasing the finest ultraviolet system on the market.

For over thirty years, Aqua Ultraviolet has manufactured ultraviolet systems that are in use in various industries, including aquaculture, public and commercial aquariums, educational institutions, government agencies and research organizations throughout the world.

Aqua Ultraviolet sterilizers are used as a control to destroy single celled organisms, water borne bacteria, viruses, algae, fungi and protozoa. Aqua Ultraviolet sterilizers are recommended for both fresh and salt water systems as well as ponds. There are no residual effects when using an Aqua Ultraviolet sterilizer. Ultraviolet will not affect Bio-filters or lower fish immune systems!

HOW ULTRAVIOLET WORKS

The ultraviolet lamp emits a germicidal ray which alters or disrupts the DNA or RNA of single celled organisms such as algae, bacteria and protozoa. By properly implementing an Aqua Ultraviolet System in-line, these organisms can be eradicated effectively without any harmful residuals.

Your Aqua Ultraviolet System was made to work as a control for green water and single celled organisms. This unit will not, nor will any other unit, completely sterilize your pond/aquarium as the pond/aquarium itself is not a sterile environment. As a control, this unit will effectively lower your water bacterial count allowing your fish to stay healthier with less risk of disease.

Aqua Ultraviolet Sterilizers work best on filtered water. Any debris in the water can inhibit UV transmission.



CAUTION: READ ALL INSTRUCTIONS CAREFULLY BEFORE BEGINNING INSTALLATION OR OPERATION.



NOTE: THE QUARTZ SLEEVE MAY NEED PERIODIC CHECKING AND CLEANING DUE TO CALCIUM AND MINERAL BUILD UP WHICH WILL DIMINISH UV TRANSMISSION.

The following instructions should answer most of the questions that you may have about the installation, operation and use of your new Aqua Ultraviolet Sterilizer. View our installation videos at www.aquauv.com. If you need technical support, we offer this service for free by telephone (800) 454-2725 or (951) 296-3480, or by fax (951) 296-3490. Our phones will be answered M-F 8:00 am - 4:30 pm Pacific Standard time except selected holidays. You may reach us through the web at www.aquauv.com.

SIZING CHART

	N of	120V			Size Fresh Water		μw/cm²	μw/cm²	μw/cm²		Water
Advantage Series Units	No. Of Lamps		Gallons	Max Flow GPH	Sterilizer* in Gallons	(EOL) GPH	(EOL) GPH	(EOL) GPH	(EOL) GPH	(EOL) GPH	Tank Gallons
Advantage 2000	1	0.48	1,500	1,000	5 - 200	642	428	321	256	214	70
Advantage 2000+	1	0.48	2,000	1,800	200 - 500	700	466	350	280	233	75

To achieve the optimum kill rates the UV must be run continuously. Constant "On and Offs" shorten the life of the lamp and transformer.

^{*}As a sterilizer (for crystal clear water) UV dosage is 30,000 µw/cm² (EOL) at max flow rate.

^{**}Salt water gallons are based on higher UV kill rate (targeting free floating parasites, i.e., Ich).

^{***}As a clarifier, water clarity is dependent on amount of sun, local temperatures, plant coverage, shallowness of pond, etc.

FREQUENTLY ASKED QUESTIONS

Where do I install my UV?

The best place to install your Aqua Ultraviolet Sterilizer is after the filter. If an after the filter installation is not feasible, your sterilizer can be installed before the filter, but it will take a little longer to work. If installed before the filter, be aware that a small rock passing from the pump can break the quartz sleeve. It is recommended that if you install your unit before your filter, you check the UV periodically for any water leakage due to a broken quartz sleeve. Be sure to have adequate pre-filtration to prevent breakage. (A broken quartz sleeve and any damage caused by a broken quartz sleeve is not covered under warranty.)

Do I have to turn my UV off when I clean my filter?

Yes, but only if the chamber is drained or if the water will remain at a stand still for more than 30 minutes. Note: Running longer than the recommended time without water flow can cause extensive damage to the unit that is not covered under warranty.

What should I expect after my UV is installed?

If your Aqua Ultraviolet system is installed after the filter and is properly sized the water should be clear in 3-5 days. If your Aqua Ultraviolet system is installed before the filter the water should be clear in 7-10 days. The green algae on the sides and bottom of the pond will not disappear, this is normal in a pond. The UV does not control this type of algae.

What's the difference between a sterilizer and a clarifier?

As a sterilizer, your Aqua UV system will keep your pond or aquarium water crystal clear, plus you will have the added benefit of bacterial control which will help keep your fish healthy and happy with less risk of disease. As a clarifier your pond will still have a green tint to it, unless you have 50-75% plant coverage or your pond is in full shade.

Do I install my UV vertically or horizontally?

You can install it either way - (see installation Instructions Page 8)

What should my flow rate be on my pond or fresh water aquarium?

The optimum flow rate on your pond or fresh water aquarium is to turn over the volume of water one time every hour to every hour and a half.

What should my flow rate be on my salt water aquarium?

Your flow rate should be 3 to 5 times the volume of water per hour.

Should any of the water bypass the UV?

No. Our UV was specifically designed to handle high flow rates for easier installation and the best water quality.

Is this unit submersible? No, not this specific series.

Does the UV light have any residual effect to the fish?

UV only affects what passes through the chamber. There is no residual effect from UV light.


Does the UV kill good bacteria?

Ultraviolet light does not discriminate about what it destroys. If good bacteria passes by the light it will be destroyed. Beneficial bacteria are colonized in your filter and along the sides and bottom of your pond. The only time those will be affected is if it becomes free floating and passes through the UV.

How often should I change my lamp?


The lamp should be changed after 14 months of continuous use. Use only Genuine Aqua Ultraviolet Lamps or the warranty is voided.

RECOMMENDED POND LAYOUT




RECOMMENDED AQUARIUM LAYOUT

HANGER UNIT




BARB X BARB



ADVANTAGE HANGER INSTALLATION

HANGER UNIT




- 1. Connect to your existing pump with a flexible hose and secure with hose clamps (hose clamps are not included, purchase separately along with your hose).
- 2. Hang the Advantage Unit on the aquarium with the hanger spout directed down inside of the aquarium.
- 3. Before you install the UV Lamp, Transformer and plug in the electrical cord, a leak test must be conducted.

LEAK TEST: Do not install Lamp or electrical components yet. After all the hose connections have been made, turn the pump on and run it for five minutes to check for leaks.


- a. If you have a leak, follow steps for trouble shooting leaks on page 9. Carefully examine this unit after installation. This unit should not be plugged in if there are any leaks on any part of this unit.
- b. If there are no leaks, continue with electrical installation.

BARB X BARB



Pond with submersible pump and filter

Pond with external pump and filter



- 1. Connect to your existing pump with a flexible hose and secure with hose clamps (hose clamps are not included, purchase separately along with your hose).
- 2. Connect a hose to opposite barb and secure with hose clamps. Hose should return water to the opposite end of your aquarium or pond.
- 3. Before you install the UV Lamp, Transformer and plug in the electrical cord, a leak test must be conducted.


LEAK TEST: Do not install Lamp or electrical components yet. After all the hose connections have been made, turn the pump on and run it for five minutes to check for leaks.

- a. If you have a leak, follow steps for trouble shooting leaks on page 9. Carefully examine this unit after installation. This unit should not be plugged in if there are any leaks on any part of this unit.
- b. If there are no leaks, continue with electrical installation.

TROUBLE SHOOTING LEAKS


Leaks from Quartz Cap / Rubber Seal

 Undo Quartz Cap and push Rubber Seal in to the Advantage body evenly. Half the Rubber Seal will still be in view. Screw on the Quartz Cap and finger tighten. Do not use a pipe wrench, pliers or any other tool. Hand-tighten only.



Leaks from Center of Quartz Sleeve

2. The Quartz Sleeve is broken and needs to be replaced. Neither the broken Quartz Sleeve nor any damage caused as a result of a broken Quartz Sleeve is covered under warranty. Contact your dealer for a replacement. Use genuine Aqua Ultraviolet parts or the warranty is voided. (See Changing the Quartz Sleeve on page 12).



INSTALLING THE LAMP



NOTE: If you touch the Lamp use denatured alcohol and a soft cloth to clean the Lamp. If you do not clean the Lamp the fingerprints will become etched into the glass which will diminish UV output and may cause premature lamp failure.



NOTE: Lamps and Quartz Sleeves should be handled with care. Lamps and Quartz Sleeves are not warranted against breakage and damage.



WARNING: Do not install the Lamp at an angle (even a slight angle); this may cause a U shaped crack at the end of the Quartz Sleeve, or possible breakage of the Lamp. If this should happen, do not proceed with the installation. Purchase a new Quartz Sleeve or Lamp from your dealer and refer to the proper installation instructions.



NOTE: Do not force the Lamp into the Quartz Sleeve.



NOTE: To achieve the optimum kill rates UV must run continuously. Constant "On and Off" shorten the life of the lamp and the transformer.

- 1. Unscrew the Davis Connector located behind the Transformer Cap, this allows your Transformer Cap to spin freely.
- 2. Plug the Lamp flush into the Lamp End Connector.

 If the Lamp is not plugged in all the way it may cause damage to the unit and is not covered under warranty.
- 3. Insert the Lamp straight into the Quartz Sleeve. Be careful, inserting the Lamp at an angle, even a slight angle, can cause a "U" shaped crack in the Quartz Sleeve.
- 4. Screw on the Transformer Cap. Do not over tighten. This is a connection only and is not in contact with water.
- Screw on Transformer Cap

 Screw on Davis Connector

Transformer Cap


- 5. Tighten the Davis Connector located behind the Transformer Cap.
- 6. **FINAL LEAK CHECK**: Do not plug the Sterilizer into power yet, turn on the pump, let water run for 5 minutes and check for leaks.
- 7. Once a leak test is completed, and there are no leaks, plug the Transformer into a GFCI outlet.




CAUTION: Always turn off the pump and disconnect electricity from the unit prior to any maintenance.

Changing the Lamp Transformer Cap Davis Connector Lamp End Connector


- 1. Unplug the UV from the power source and turn off the pump.
- 2. Unscrew the Davis Connector located behind the Transformer Cap, this allows your Transformer Cap to spin freely.



3. Unscrew the Transformer Cap.




- 4. Slide Lamp out, be careful not to slide the Lamp out at an angle, even a slight angle, this may cause a "U" shaped crack at the end of the Quartz Sleeve, or possible breakage of the Lamp.
- Disconnect the Lamp End Connector from the old Lamp. Use only Genuine Aqua Ultraviolet Lamps or the warranty is voided.




- 6. Plug the new Lamp flush into the Lamp End Connector. If the Lamp is not plugged in all the way it may cause damage to the unit and is not covered under warranty.
- 7. Insert the Lamp straight into the Quartz Sleeve. Be careful, inserting the Lamp at an angle, even a slight angle, can cause a "U" shaped crack in the Quartz Sleeve.
- 8. Screw on the Transformer Cap. Do not over tighten. This is a connection only and is not in contact with water.
- 9. Tighten the Davis Connector located behind the Transformer Cap.
- 10. FINAL LEAK CHECK: Do not plug the Sterilizer into power yet, turn on the pump, let water run for 5 minutes and check for leaks.
- 11. Once a leak test is completed and there are no leaks, plug the Transformer into a GFCI outlet.

CLEANING OR CHANGING THE QUARTZ SLEEVE

- 1. Unplug the UV from the power source and turn off the pump.
- 2. Unscrew the Davis Connector located behind the Transformer Cap, this allows your Transformer Cap to spin freely.



3. Unscrew the Transformer Cap.




- 4. Slide Lamp out, be careful not to slide the Lamp out at an angle, even a slight angle, this may cause a "U" shaped crack at the end of the Quartz Sleeve, or possible breakage of the Lamp.
- 5. Remove the Quartz Cap.



NOTE: The Lamps and Quartz Sleeves should be handled with care. Lamps and Quartz Sleeves are not warranted against breakage and damage.

6. Using a soft cloth, grasp the Quartz Sleeve and turn and pull the Quartz Sleeve along with its Rubber Seal.



- 7. Once the Quartz Sleeve is removed, it can be cleaned with Lime Away or similar products.
- 8. Replace the Rubber Seal if necessary. The Rubber Seal should be replaced at 14 months with the lamp change.
- 9. To reinstall the Quartz Sleeve, carefully insert the Quartz Sleeve into the end of the Advantage Unit. Use Only Genuine Aqua Ultraviolet Quartz Sleeves or the warranty is voided.
- 10. Push the Rubber Seal into the UV Body. The Rubber Seal should be 1/4" from the end of the Quartz Sleeve, 1/2 of the Rubber Seal should be visible.
- 11. Screw on the Quartz Cap. Do not use a pipe wrench, pliers or any other tool on this unit. Tighten by hand only.

CLEANING OR CHANGING THE QUARTZ SLEEVE

- 12. **Run Leak Test**. Do not install Lamp or electrical components yet. After the Quartz Sleeve has been installed, turn on pump and run it for five minutes to check for leaks. If there are leaks see page 9 for solutions.
- 13. When there are no leaks install the lamp. Refer to page 11.



CAUTION: GFCI Information: The warranty is null and void if the unit is not plugged into a G.F.C.I. (Ground Fault Circuit Interrupter). A Surge Suppressor should be added for extra protection, it is not required, but recommended.



CAUTION: Improper connection of the equipment to a grounding conductor can result in the risk of electrocution. Check with a qualified electrician or service person if there is any doubt the outlet is being properly grounded. Do not modify the plug provided with the unit; if the plug does not fit the outlet have a proper outlet installed by an electrician.



CAUTION: Do not lay the transformer on the ground. Prevent the transformer from lying in standing water.



CAUTION: Do not operate unit if it has a damaged cord or plug, if it is malfunctioning, or if has been dropped or damaged in any manner.




CAUTION: If the unit falls into the water, DO NOT reach for it. First unplug the unit and then retrieve it. If the electrical components of the unit get wet unplug the unit immediately.




CAUTION: If an extension cord is necessary a cord with a proper rating should be used, a cord rated for fewer amperes or watts than the unit rating may overheat. Care should be taken to arrange the cord so that it will not be tripped over or pulled.

Winterizing

If you are using your Advantage Unit outdoors in climates where freezing is possible, the unit must be removed and stored for winter. The lamp should be removed from the unit and stored separately to avoid breakage.



Use Only Genuine Aqua Ultraviolet parts or the warranty is voided.



WARRANTY RETURNS OR REPAIRS

Warranty Returns or Repair Returns:

Please call Aqua Ultraviolet at (800) 454-2725 for a "Return Merchandise Authorization" (RMA) number. You must have a valid RMA from an Aqua Ultraviolet customer service representative before sending any product in for warranty or repair. Please have your serial number, date of purchase and product type available when calling for an RMA number.

All warranty returns or repair returns must come freight prepaid with an RMA number clearly marked on outside of the box. All other returns will be refused. Aqua Ultraviolet will not be liable for any shipping cost to return warranty or repair items. Include a note in the box with your RMA number, name, address, daytime phone number and brief description of the reason for return or repair.

Be sure to return product in the same packing or similar packing and insure the package (we recommend sending it UPS). If you do not have or can't locate proper packaging, please call our customer service department and we will send you packaging for a minimal charge.

Aqua Ultraviolet shall not be responsible for damage or loss done by the shipper. Nor shall Aqua Ultraviolet be responsible for merchandise that arrives damaged due to improper packaging. All claims for loss and damage must be filed by the customer with the shipper.

If unit is found to be out of warranty we will contact you with the cost of repair. Your authorization is required prior to making any repairs.



42371 Avenida Alvarado Temecula, CA 92590 TOLL FREE: (800) 454-2725 TEL: (951) 296-3480 FAX: (951) 296-3490 www.aquauv.com