Installation Guide



Installing HydroBlox is much faster and easier than any other drainage system. NO filter fabric or aggregate is required. Simply trench and drop the HydroBlox plank in.

Tools Required

- Trenching machine
- Shovel
- HydroBlox
- Safety Glasses

Step One

Layout of the drain field is done using the same pattern as with traditional systems.



Step Two

Dig a trench between 2" and 4" wide and 12" deep.



Step Three

Slide the HydroBlox vertically into the trench. Take care to 'butt' the planks against each other. Perfect contact between planks is not necessary. HydroBlox can be easily cut using a circular saw.





Step FourFill the trench with the previously excavated soil and reseed.



Connecting to Existing Drainage Systems

In most cases, the layout of HydroBlox can direct the water to a dry area in the yard. Should it be necessary to connect HydroBlox to a solid stormwater pipe, this is easily accomplished by using a HydroBlox Transition Box





Videos and installation hints and other uses for HydroBlox are available on line at <u>hydroblox.com</u> Support is available at <u>help@hydroblox.com</u> and at 724-719-2660.

