

STEP INSTALLATION

- 1. Place the step in the appropriate location on your pool installation. The hardware package consists of the following components:**
 - A. face plate with gasket**
 - B. four leveling columns**
 - C. stainless steel face plate screws.**
- 2. Place the four leveling columns in the socket provided on the backside of the step. Cut support pipe to proper length as needed for your step.**
- 3. Properly level the step horizontally and vertically. Check the step to make sure it is plumb with the flanking wall panels.**
- 4. To insure proper installation, clamp the step to the flanking wall panels. This will allow proper wall and drilling alignment.**
- 5. Pour a concrete bond beam at the base of the step at the same time the beam is poured around wall and brace system.**
- 6. Backfill the step cavity with granular material to achieve maximum compacting. Do not use clay, dirt, soil or other earthen materials for backfill. This material will not compact properly, leaving hollow cavities which will weaken step support over time.**

