

Figure 1. Supply and Return lines on the same header. Solar Valve should be in the ON position while operational.




Figure 2. Supply and Return lines on opposite Headers. Solar Valve should be in the OFF position while operational.