

T-CELL-9 GLX-CELL-9-W

NEW MENU SETTING REQUIRED!

You must configure your controller for use with the T-CELL-9 or GLX-CELL-9-W chlorinator cell *before* attempting to operate. Incorrect configuration will cause inaccurate salt readings, improper operation, and possible system shutdown.

The T-CELL-9 and GLX-CELL-9-W are designed for pools up to 25,000 gallons. They are compatible with the following models only and will NOT work with earlier versions:

- AQR (Aqua Rite - all 2009 or later) - firmware version 1.5 or later
- AQR-PRO (Aqua Rite Pro) - operating with firmware 1.10 or later
- PL-P-4 (Pro Logic P4) - operating with firmware 4.10 or later
- PL-PS-x (Pro Logic PS) - operating with firmware 4.10 or later

Connecting to an AQR:

1. Slide the Main Switch to the "Auto" position.
2. Push the Diagnostic button repeatedly until "t-xx" appears on the display ("t-15" is the factory default).
3. To change cell type, slide the Main Switch from "Auto" to "Super Chlorinate" and back to "Auto". Repeat this process until the "t-9" is displayed.
4. Push the Diagnostic button to exit.

Connecting to an AQR-PRO:

1. Verify that the firmware version is 1.10 or greater by pushing the "Info" button, then ">" repeatedly until the firmware revision is shown. If the firmware version is less than 1.10, the T-CELL-9 or GLX-CELL-9-W cannot be used.
2. Access the Settings Menu by pushing the "Settings" button.
3. Push ">" until Chlor. Config is displayed, then push "+".
4. Push ">" repeatedly until "Cell Type" is displayed.
5. Push "+" or "-" until "T-CELL-9" is displayed.
6. Exit Settings Menu by pushing the "Info" button.

Connecting to a PL-P-4 or PL-PS-x:

1. Verify that the firmware version is greater than 4.10 by entering the Diagnostic Menu and repeatedly pushing the ">" until the Main Firmware revision is shown. If the firmware version is less than 4.10, the T-CELL-9 or GLX-CELL-9-W cannot be used.
2. Enter the Configuration Menu.
3. Push ">" until Chlor. Config is displayed, then push "+".
4. With the Chlorinator Enabled, push ">" repeatedly until "Cell Type" is displayed.
5. Push "+" or "-" until "T-CELL-9" is displayed.
6. Exit Settings Menu by pushing the "Menu" button.